

BONCREAT CONCRETE CIRÉ GENERAL

Surface application method

- Respect the dilatations or apply appropriate reinforcement.
- The surface should always be dry, smooth, clean, dust-free, grease-free, without holes or cracks, stable, stress-free and have a fine structure.
- The thickness of the concrete ciré is minimal and is not suitable for filling.
- Improve the surface if necessary by dispersing a layer of sandy Boncreat epoxy (always consult product sheets).

Concrete ciré work method

- Apply The Boncreat Ciré Primer (if necessary) with a fur roll and allow to dry.
- Spread the first layer of concrete ciré with a Boncreat spatula into a thin covering layer and let it dry for at least 3 hours, always check if it is completely dry.
- Sand lightly with a 120-150 grain and remove the dust with a dry cloth and/or vacuum cleaner.
- Place the second layer of concrete ciré with a Boncreat spatula and create the desired effect. Allow to dry for at least 3 hours, always check if it is completely dry.
- Sand lightly with a 120-150 grain and remove dust.
- Apply the first layer of the lacquer evenly with a clear lacq roller.
- Lacq it all at least twice. Allow to dry for at least 6 hours in between layers.
- After 24 hours, walkable and carefully loadable.
- After 10 days, it is completely hardened and loadable.

Floors

- Check for irregularities, cracks, holes, etc. repair properly, remove dirt, grease and dust. An anhydrite basement should always be sanded, laid for at least 6 weeks and have a humidity percentage of up to 0.5%. A sand-cement bed layer must be placed for at least 28 days with a maximum humidity percentage of 2.5%.
- Improve (if necessary) the surface by applying a layer of Scratch Boncreat epoxy and/or leveling a sublayer that will become smoother but also harder, and more durable. Always do this with a stress-free leveling coating, for example Eurocol 924.
- As far as floor heating is concerned; The start-up procedure must be followed at all costs.

More information, as well as manuals and movies can be found on our website

www.boncreations.nl

Tip: Provide a clean, dry entrance mat at the outdoor doors