

BONCREAT METAL STUC

- If necessary, apply a layer of Boncreat Primer with a fur roll and allow to dry for 60 minutes.
- Apply the Stuc Metal with a Boncreat spatula in a thin base layer and create the desired effect. Allow to dry for at least 3 hours.
- Lightly sand with a grain of 150 and dust with a dry cloth!
- Then apply a Metal Finish finish layer with a Boncreat spatula and create the desired image/effect and let it dry.
- Satisfied? You can repeat with a layer of metal finish.
- Allow to dry for at least 3 hours and if wanted apply a layer of Boncreat Ecosealer or a PU boncreat 2K layer, repeat after 12 hours if necessary.
- After use please immerse the rags due to the risk of spontaneous combustion.

Basic surface requirements: stable, dry (permanently), smooth, clean (and dirt).

Stuc Metal is not an equalization or filling product.

PAINTING BONCREAT ASPECT CONCRETE

- Apply Concrete Look paint in a thick layer with a brush or roller. Create the desired effect with the spatula (on wet paint). For a rough effect, do it irregularly with relief, for a more uniform effect, flatten it a little.
- If it's your first time, do the job with 2 people, one person spreads with the roller and the other with the spatula.
- Allow to dry for at least 6 hours, then check to see if the surface is dry.
- Once dry, lightly sand the surface with a grain 400 or more to create the concrete appearance. Remove the dust.
- For extra effect, you can dry-chip the surface with the spatula in an angular position of about 45 to 60 degrees. This makes the whole shine and a dark grey-black effect forms. Stop when you're satisfied.
- If you want to make Boncreat Beton Look paint more resistant to water and dirt, you can provide boncreat Sealox Impregne, it's an invisible layer.

PLEASE NOTE THAT THE COLOURS OF CONCRETE PAINT AND CONCRETE CIRE ARE NOT THE SAME.